

DSP PRESET DIP SWITCH POSITIONS

	Dip Switch Number							
Preset Number	2	3	4	5	6			
	Up/Down (U/D)						DSP Preset Description	Amplifier Output Mode
0	D	D	D	D	D		Flat EQ Stereo*	Stereo
1	D	D	D	D	U		Stylus-170	Stereo
2	D	D	D	U	D		Stylus-270	Stereo
3	D	D	D	U	U		Stylus 370	Stereo
4	D	D	U	D	D		Stylus 470	Stereo
5	D	D	U	D	U		Garden Oasis Essentials Outdoor System (Supports up to 2 subwoofers)	Stereo
6	D	D	U	U	D		Mono Garden Oasis Essentials Outdoor System (Amp in Bridged Mode - Parallel Wiring) (Supports up to 2 Subwoofers)	Bridged Mono
7	D	D	U	U	U			
8	D	U	D	D	D		GO4 (Up to 4x GO4 per channel)	Stereo
9	D	U	D	D	U		GO6 (Up to 4x GO6 per channel)	Stereo
10	D	U	D	U	D		Rock-Monitor-60-SM	Stereo
11	D	U	D	U	U		Rock-Monitor-80-SM	Stereo
12	D	U	U	D	D			
13	D	U	U	D	U			
14	D	U	U	U	D			
15	D	U	U	U	U			
16	U	D	D	D	D			
17	U	D	D	D	U		SFC12-SW**	Bridged Mono
18	U	D	D	U	D			
19	U	D	D	U	U		Generic 8 ohm CI Subwoofer** (Amp in Bridged Mode)	Bridged Mono
20	U	D	U	D	D		RVC-12SQ + Back Box** 1 Sub = Set Sub to X-300 Mode (4 ohm) Up to 2 Subs = Set Subs to X-850 Mode (Amp in Bridged Mode - Each Sub Paralleled)	Bridged Mono
21	U	D	U	D	U		RVC-12SQ (No Back Box)** 1 Sub = Set Sub to X-300 Mode (4 ohm) Up to 2 Subs = Set Subs to X-850 Mode (Amp in Bridged Mode - Each Sub Paralleled)	Bridged Mono
22	U	D	U	U	D		Garden Oasis Sub 8** (Amp in Bridged Mode - Parallel Sub Voice Coils)	Bridged Mono
23	U	D	U	U	U		DUAL Garden Oasis Sub 8** (Amp in Bridged Mode - Each Subwoofers voice coils paralleled into 1 amplifier channel)	Bridged Mono
24	U	U	D	D	D		DCS-208FR3 Sub (Amp in Bridged Mode)**	Bridged Mono
25	U	U	D	D	U		DUAL DCS-208FR3** (Amp in Bridged Mode - Each Sub Paralleled)	Bridged Mono
26	U	U	D	U	D		DCS-208IW3 Sub (No Back Box)** (Amp in Bridged Mode)	Bridged Mono
27	U	U	D	U	U		DUAL DCS-208IW3 (No Back Box)** (Amp in Bridged Mode - Each Sub Paralleled)	Bridged Mono
28	U	U	U	D	D		DCS-208IW3 Sub + Back Box** (Amp in Bridged Mode)	Bridged Mono
29	U	U	U	D	U		DUAL DCS-208IW3 Sub + BackBox** (Amp in Bridged Mode - Each Sub Paralleled)	Bridged Mono
30	U	U	U	U	D		GO10SW**	Bridged Mono
31	U	U	U	U	U		GO12SW**	Bridged Mono

*Output limited to 250W @ 4ohms and 125W @ 8 ohms. **All subwoofer presets have an 80Hz Low-Pass filter when using the Left and Right input. The Subwoofer input passes all signals.